
QUICK GUIDE

See manual for more functions and details









Before you operate the product, you must read and understand the safety chapter in the manual.

Download the Sordin Share app from Google Play or App Store.

FUNCTIONS

Charge battery

Connect the charger cable to the outlet on the left earmuff.

Power on

Push and hold multifunction [•] for 2 seconds.

Power off

Push and hold multifunction [• 1 for 2 seconds.

Pairing with a mobile phone

Push multifunction [**0**] for 5 seconds, until voice feedback "MOBILE PHONE PAIRING".

In your phone, search for Bluetooth devices and select "Sxxxxxx" (number marked on the unit).

Accept/end a phone call

During incoming call, tap multifunction [0] to answer.

Push and hold multifunction [•] for 2 seconds to reject call.

To end phone call, tap multifunction [•].

Join an existing intercom group

Push and hold intercom [● ●] for 5 seconds, until voice feedback "START GROUPING".

Create & allow others to join an intercom group

Push and hold intercom [● ●] for 5 seconds, until voice feedback "START GROUPING".

Then tap intercom [● ●] 1-5 second after step 1.

Sordin recommend using the mobile app for group management.

Adjust volume

To adjust the volume in current mode, tap volume down [-] or volume up [+].

Stream/stop music

Tap multifunction [•] wait until you hear "Music on/off" and tap again.

Change track during streaming

Tap multifunction [•] wait until you hear "Next track" and tap again.

Tap multifunction [•] wait until you hear "Previous track" and tap again.

Turn FM radio on/off

Tap multifunction [•] wait until you hear "Radio on/off" and tap again.

Change radio station

Tap multifunction [•] wait until you hear "Next station" and tap again.

Tap multifunction [•] wait until you hear "Previous station" and tap again.

Scan radio stations

Tap multifunction [•] wait until you hear "Auto scan" and tap again.

Turn Level Dependent Ambient Sound on/off

Tap intercom [●●] wait until you hear "Turn Level Dependent on/off" and tap again.

To adjust Level Dependent Ambient Sound

Tap intercom [●●] wait until you hear "Level Dependent volume control" tap [●●] and then use [■] [♣].

VOICE COMMANDS

Use voice commands for hands-free operation of features. Loudly say a command to perform an action.

,,	
То	Say
Turn on the radio	"Hey Sordin, radio on"
Turn off the radio	"Hey Sordin, radio off"
Skip to the next preset radio station	"Hey Sordin, next station"
Skip to the previous preset radio station	"Hey Sordin, previous station"
Turn on music	"Hey Sordin, music on"
Turn off music	"Hey Sordin, music off"
Play the next music track	"Hey Sordin, next track"
Play the previous music track	"Hey Sordin, previous track"
Raise volume	"Hey Sordin, volume up"
Lower volume	"Hey Sordin, volume down"
Mute microphone	"Hey Sordin, mute audio"
Unmute microphone	"Hey Sordin, unmute audio"
Call the default number (configurable)	"Hey Sordin, speed dial"
Redial the last number	"Hey Sordin, redial number"
Access Siri (iOS device)	"Hey Siri"
Access Google (Android device)	"OK Google"
Check the battery status	"Hey Sordin, battery status"
Initiate an emergency call (configurable)	"Hey Sordin, emergency"
Initiate private chat	"Hey Sordin, private chat on""
Terminate private chat	"Hey Sordin, private chat off"
Current channel number	"Hey Sordin, what is my channel?"
To listen to all available commands	"Hey Sordin, command list"
Terminate private chat Current channel number	"Hey Sordin, private chat off" "Hey Sordin, what is my channel?"

BUTTONS

