



3M™ 6000 Series Half Mask

Care and Maintenance



To maintain protection levels, optimise the effective lifetime of the equipment and avoid the additional cost of replacement, it is extremely important to carry out regular checks and maintenance on Reusable Respirators.

Before Use

- Inspect respirator for incorrectly fitted and/or damaged parts. Replace if necessary
- Inspect the exhalation valve and seat.

Monthly

- Carry out all the 'Before Use' inspections
- Check:
 - Face Seal
 - Straps and Head harness
 - Valves
- Create record of this monthly check

After Use

- Cleaning is recommended after each use
- Remove the gas/vapour and/or particulate filters
- Clean with 3M™ 105 wipe or by immersing in warm cleaning solution, water temperature not to exceed 50°C and scrub with a soft brush until clean
- Rinse in fresh warm water
- Air dry in a non-contaminated atmosphere

Ordering Consumables, Repair Parts and Accessories

To request a quote or place an order for these items, please contact your 3M Approved Distributor.

Further Information and Advice

If you require additional guidance on the Care and Maintenance of your 3M™ Reusable Respirators, please contact the Helpline or your local 3M representative.

Occupational Health & Environmental Safety Group

3M United Kingdom plc
3M Centre,
Cain Road, Bracknell
Berkshire RG12 8HT
Tel: 0870 60 800 60
www.3M.co.uk/ohes

3M Ireland Limited
The Iveagh Building
The Park
Carrickmines
Dublin 18
Tel: 1 800 320 500

3M is a trademark of 3M Company
Please recycle. Printed in UK.
© 3M 2010. All rights reserved.

REPLACE ALL DAMAGED PARTS IMMEDIATELY TO ENSURE CORRECT LEVELS OF PROTECTION

3M Health & Safety Helpline
Monday - Friday 9 to 5

0870 60 800 60 UK
1 800 320 500 IRELAND

EAR
PELLTOR